

- Fit more in with each load with VarioFlex baskets
- Efficient performance delivered by the EcoSilence Drive

Get your dishes washed quickly

Need your dishes cleaned in a hurry? The Bosch **Serie 4 SMS46IW04G Full-size Dishwasher's** VarioSpeed Plus option reduces program times by up to 66% without compromising on the cleaning performance. Ideal for busy households or when you're hosting a dinner party, you'll get clean and dry dishes without having to wait around.

Extra Dry program

Use your cutlery and cookware sooner after it's washed with the ExtraDry program, which uses higher temperatures to quicken up the drying process.

You can also use the HygienePlus option with many of the programs. Antibacterial cleaning is ideal for homes with small children or allergy sufferers, cleaning everything to a high standard.

Fit more in with each load

Offering a generous 13 place setting capacity, you can wash more with each load - the Bosch **SMS46IW04G Dishwasher** features adjustable VarioFlex Baskets and a VarioDrawer. Make more room for cups, saucers, and cutlery by moving shelves and racks as you require. There's also a height adjustable top basket – perfect for taller items on the lower shelf.

Efficient performance

Worried about your energy bills? The EcoSilence Drive delivers a quiet and fast performance without using too much energy, so you can enjoy peace of mind while your dishes get cleaned.